



# PROFESSIONAL MEETING MICROPHONE

## INSTRUCTION MANUAL

### TS-338

This product is specially designed and made for various kinds of meeting, lectures, broadcasting, recording occasion and etc. We use high quality condenser cartridge to make sure that the microphone has high sensitivity and good frequency responsency, please read the following instruction carefully before you use the microphone.

#### Specifications

Capsule Type: Condenser

Polar pattern: Cardioided

Frequency Response: 20-20KHz

MIC Sensitivity:  $-40\pm 2$ dB

Output Impedance:  $75\Omega$

Power Supply: DC3V / 48V

#### Operation Instruction

1. Insert the battery with the correct polarity and connect the audio cable.
2. Adjust the volume of the amplifier to the minimum position.
3. Turn on the power switch of the amplifier and meeting microphone, and then adjust the volume of the amplifier slowly to desired level.
4. Under the base there has a prelude music volume control, which can adjust the volume.

#### Attentions

1. The speaker will whistle if microphone is too near the speaker or the volume of the amplifier is too high, take care of keep certain distance and to limit the volume of the amplifier otherwise damage maybe cause to the amplifier or the speaker.
2. Take out the battery if the microphone will not be used for a long time. The device may be damaged the spillage of the degenerative battery.
3. The T-338 is a phantom power microphone. 3V battery power is a temporary way for power supply. For long-term installation and use, it is recommended to use 48V phantom power to avoid frequent battery replacement.